



**INSTALLATION INSTRUCTIONS FOR  
PART 1602S  
GL1500 SMOKE AIR DAMPNER**

**NOTE:** Hooks are long to accommodate chrome grills. Cut ¼” off if you do not have chrome grills. While installing, the lower air vents must be open. Check your engine temperature. Not for use in warm weather.

