

Designed & Mfg. by V&P 77 Milton Ave. Blackstone, MA 01504
Tel. 508-883-0317 1-800-671-2141 for orders only
vpjean@aol.com Web www.vpaccessories.com

To Install front 1800 shields, remove lower screw at bottom of cowl, install shield long narrow end up with clip on the inside of vertical chrome bar, secure bottom with 6mm screw furnished, use nylon spacer between shield and cowl.
Lt. Bronze Shield shown, Chrome Shield similar

