



MOUNTING INSTRUCTION FOR PART NUMBER 18541 GL1800 Passenger Floorboard Risers

1. Place bike on center stand.
2. Using a 8mm allen wrench, remove the two allen bolts which secure the floorboards to the frame.
3. With floorboard removed, install adapter plate using the same 8mm allen bolts going through the unthreaded holes. Spacers are placed on the inboard side of the adapter plate. Threaded holes go on top.
4. Remount floorboards with 5/16" x 3/4 bolts supplied.

