



MOUNTING INSTRUCTIONS FOR MUDFLAP

GL1800
18741-176
18741-179
18741-180

GL1500
15471-176
15741-179
15741-180

Remove the two 5mm screws from each side of the rear fender extension. Insert the mounting plate between the two parts. Reinstall the screws and mount the flap to mounting flap.



18741-176



18741-179



18741-180

For lighted mudflaps, splice wires into the running or brake lights. **NOTE:** Ensure all wires are secure and away from moving parts.

133 Gold Street Worcester, MA 01608 PH: (508)791-7552 (800)821-9861 FX: (508)793-2919
info@addonaccessories.net www.addonaccessories.net



MOUNTING INSTRUCTIONS FOR MUDFLAP

GL1800
18741-176
18741-179
18741-180

GL1500
15471-176
15741-179
15741-180

Remove the two 5mm screws from each side of the rear fender extension. Insert the mounting plate between the two parts. Reinstall the screws and mount the flap to mounting flap.



18741-176



18741-179



18741-180

For lighted mudflaps, splice wires into the running or brake lights. **NOTE:** Ensure all wires are secure and away from moving parts.

133 Gold Street Worcester, MA 01608 PH: (508)791-7552 (800)821-9861 FX: (508)793-2919
info@addonaccessories.net www.addonaccessories.net