



Mounting Instructions GL1800 LED SIDE LIGHTS Part Number 45-1611NUA

NOTE: Read instructions thoroughly before installing.

1. Remove the Phillips screws on the underside of the mirrors. Remove the boot and mirror. Unplug the wires from lights.
2. On the LED side lights, plug the long black wire into the red, white and black wires harness. Remove the fairing molding and route this wire harness to the mirror cavity.
3. Cut back some of the shrink-wrap to expose the three wires in the mirror cavity. Peel back all three wires on both sides.
4. Connect the black wires from the LED side lights to the green wires on both sides. Connect the yellow wires to the orange on the left side and the light blue on the right. Connect the red wires to the remaining wires (hot). Carefully solder and tape the wires.

4a. On some later model bikes, the following wiring is as follows:

RIGHT SIDE	Blue/White	Hot (Running Light)
	Blue	Turn Signal
	Green	Ground
LEFT SIDE	Orange/White	Hot Running Light
	Orange	Turn Signal
	Green	Ground

5. Remove the clear plastic airfoils above the cylinder heads. Using Windex, thoroughly clean the chrome strip and put the LED side lights in place. Plug the black harness into the light.
6. Reinstall fairing molding and mirrors.

NOTE: If the running lights are brighter than the turnsignal light, unplug the light; turn the plug 180 degrees and plug it back in.