



MOUNTING INSTRUCTIONS FOR 45-1620A GL1800 DRIVER BOARD SETS WITH HEEL TOE SHIFTER

Note: Read instructions thoroughly before installing.

1. Place bike on center stand.
2. Remove the two bolts that hold the stock left side foot peg bracket and remove bracket and foot peg.



3. Install shifter slot over shifter peg.



4. With the longer bolts supplied, sandwich the Heel Toe Shifter plate between the frame and chrome bracket provided.



4.

5. Screw in bolts and secure tightly. Double check the tightness per service manual.

6. Replace stock peg with the driver board provided.

7. Install driver board with hardware provided.



8. Right side. Remove stock bracket and peg. Replace with chrome bracket and floorboard with stock bolts.