



Installation Instructions for Part 45-8541 GL1500 Chrome Key Cover

1. Place bike on center stand.
2. Remove the OEM key cover by pressing down and turning counter clock wise.
3. Put a little lubricant on the tabs of the new part.
4. Install chrome cover and turn clock wise to secure.



133 Gold Street Worcester, MA 01608
(508)791-7552 (800)821-9861

info@addonaccessories.net
FAX(508)793-2919