



MOUNTING INSTRUCTIONS FOR  
**NOVIBE© COMFORT GRIPS**  
PART NUMBER 45-1243 (Revised Apr 2015)

**Note: Read instructions thoroughly before installing.**

1. Place bike on center stand.
2. Remove anti-vibration dampers, if the bike has them.
3. Remove old grips.
4. Clean left and right side clutch and brake handlebar/sleeve **with sandpaper and alcohol. Check new grips for any contaminates and clean.**
5. Left side – Install NOVIBE© grip using adhesive to secure grip.
6. Right side –

a. If using damper, remove chrome end caps from NOVIBE© grips. Insert the socket head set screw provided with 3mm allen wrench into damper bolt hole and screw until snug (see figure 1). Install grip same as left side. Insert end chrome end cap with hole (figure 2). Be sure that there is sufficient play in the throttle and freedom of movement. Reinstall damper and double check throttle movement. If throttle is not free, back out set screw one turn. Use blue lock tight when reinstalling the damper screw.

b. If no damper is used, install grip with adhesive and do not use set screw. Install chrome end cap in figure 3 at the end of the grips.



Figure 1



Figure 2



Figure 3



Installed with damper  
Shown with optional Rist Rest© Part 45-1237R



Installed with end cap

**Warning: On the adhesive supplied, read all cautions and avoid contact with skin or eyes. This adhesive dries very fast and caution must be taken when applying. Be sure to protect any area that you do not want to have this adhesive to over flow on. Test fit grips before using adhesive and mark position before adding adhesive. Evenly distribute adhesive by rotating the grip back and forth while sliding the handlebar.**

**Note: It is the installer's and driver's responsibility to ensure the grips are working properly and are periodically inspected.**