



Mounting Instructions For GL1800 FUEL DOOR ACCENT

Part	45-1498 12-16 and 06-16 Airbag
Part	45-1402 01-10 Non Airbag

1. Check placement of fuel door accent on bike.
 2. Clear area where the fuel door accent will go with alcohol pad provided.
 3. Remove the backing on two-sided tape.
 4. Carefully place fuel door accent piece in place, hold for 30 seconds.
- Do not ride bike for 24 hours to ensure adhesive is set.



45-1498



45-1402