

## CHROME SADDLEBAG GUARD COVERS #45-1622C

### INSTALLATION INSTRUCTIONS

1. REMOVE FOG LIGHT COVER ( LEFT OR RIGHT ) ( PHOTO 1 ) BY REMOVING THE TWO SOCKET HEAD SCREWS AND PULLING FORWARD.
2. REMOVE ( LEFT OR RIGHT ) SIDE LOWER COWL ( PHOTO 2 ) BY REMOVING TWO SOCKET HEAD SCREW. RELEASE THE GROMMET, SNAP CLIP AND TAB BY GENTLY PULLING SIDE COWL AWAY FROM THE MOTORCYCLE.
3. REMOVE BLACK ENGINE GUARD COVER BY REMOVING THE TWO LOCKING PINS.
4. INSTALL IN REVERSE ORDER.
5. REPEAT SAME PROCEDURE ON OTHER SIDE OF MOTORCYCLE.

PHOTO 1



PHOTO 2

