



**MOUNTING INSTRUCTIONS FOR
Part 45-1233C
2018 GL1800 Chrome Windshield Strut
Covers**

Note: Read instructions thoroughly before installing.

1. Raise windscreen to full high position.
Note: To hold the windscreen in the full high position, turn off the ignition switch while holding the windscreen switch up. The windscreen will stay at full high position
2. Remove the reusable plastic rivet from the inside windscreen support by pushing in on the center of the rivet with a pen or small screw driver. Pull rivet from the windscreen support.
3. Remove stock windscreen strut cover by sliding down and off.
4. Put chrome strut cover in place and reinstall reusable plastic rivet.
5. Please follow these procedures for both the left and right side Chrome Windshield Strut Covers.

