



**INSTALLATION INSTRUCTIONS FOR
Part 114A
GL1100 AMBER SIDE LIGHT KIT**

Note: Read instructions thoroughly, drilling required.

1. Remove right hand storage bin and left hand lower from fairing.
2. Remove stock reflectors and bezel.
3. Drill $\frac{1}{4}$ " hole in bezel as illustrated.
4. Drill a $\frac{5}{16}$ " hole in fairing to match holes in bezel.
5. Remove turn signals.
6. Mount side marker lights. Tighten until snug.
7. Install wire through side marker light openings.
8. Locate the dual female plug in the left turn signal opening. Connect the wires from the kit to the plug with connectors provided; green being ground and brown being positive.
9. Reinstall and check for tightness.

