



Installation Instructions Part 15373-426 GL1500 Chrome Carb Covers

NOTE: Read Instructions Carefully Before Installing

1. Place motorcycle on the center stand.
2. Remove the left and right side covers by pulling at the rear of the cover.
3. Unscrew the upper side cover from the bottom side covers
4. Install the new chrome cover replacement

NOTE: Put a small amount of oil on the grommets. Reinstall the side cover.



133 Gold St, Worcester, MA 01608 PH: 508-791-7552 800-821-9861 FX: 508-793-2919
Email: info@addonaccessories.net web: www.addonaccessories.net



Installation Instructions Part 15373-426 GL1500 Chrome Carb Covers

NOTE: Read Instructions Carefully Before Installing

1. Place motorcycle on the center stand.
2. Remove the left and right side covers by pulling at the rear of the cover.
3. Unscrew the upper side cover from the bottom side covers
4. Install the new chrome cover replacement

NOTE: Put a small amount of oil on the grommets. Reinstall the side cover.



133 Gold St, Worcester, MA 01608 PH: 508-791-7552 800-821-9861 FX: 508-793-2919
Email: info@addonaccessories.net web: www.addonaccessories.net