



**INSTALLATION INSTRUCTIONS FOR
PART 1601
GL1500 & GL1200 WINGLETS**

Read instructions thoroughly before installing. Drilling required.

1. Mount hinges to front face of deflector with nylon screws supplied.
2. Place deflector into position with scoop portion behind windshield.
3. Space between windshield and deflector must be $\frac{3}{16}$ ".
4. Locate deflector close to bottom of windshield with clearance for handlebars and mirrors, etc.
5. Mark windshield screw-hole locations, using the hinges as your template.
6. Carefully drill $\frac{7}{32}$ " holes.
7. Hinge machine screw head should be on top of hinge, tighten only by friction required for deflector use.

