



## Mounting Instructions 18-625A GL1800 & 1200 84-87 LED Caliper Cover Lights



**Note: Before drilling into the fairing, Check to see that there are no wires or Components in the way. Make sure the wires are routed safely away from moving or turning parts.**

1. Remove the left and right fairing pockets.
2. Remove the left and right fairing reflectors
3. Remove the socket/bulb assembly from the lights.
4. Apply masking tape over the reflector area. Place the light back on tape area and trace the socket and mounting hole onto the tape.
5. Drill a 7/8" hole for the socket and a 1/4" hole for the mounting bolt.
6. Attach the light back to the fairing and install the light socket.
7. Remove the 3 sides of double tape on the lenses and push it into the light back.
8. Using the wire connectors provided, attach the green wire to ground and the brown wire on the taillight or to an accessory light switch.