

Installation Instructions for GL1800 Chrome Lower Vents 2006-2010 Part 45-1256

- 1. Place bike on center stand.
- 2. Carefully remove lower air vent by prying the sides and snapping it out.
- 3. Install new vent by pushing into opening until firmly in place.



133 Gold Street Worcester, MA 01608 (508)791-7552 Email: info@addonaccessories.net w

! (800)821-9861 FAX (508)793-2919 www.addonaccessories.net