



MOUNTING INSTRUCTIONS FOR
Part 45-1295
GL1800 2012 Chrome Windshield Panel Mask Accent

1. Place bike on center stand.
2. Check placement of Windshield Panel Mask Accent on bike.
3. Clean area where the fuel door accent will go with alcohol pad provided.
4. Remove the backing on two-sided tape.
5. Carefully place fuel door accent piece in place, hold for 30 seconds. Do not ride bike for 24 hours to ensure adhesive is set.



133 Gold St, Worcester, MA 01608 508-791-7552 800-821-9861 fax 508-793-2919 email: info@addonaccessories.net