



## **MOUNTING INSTRUCTIONS FOR - Part 45-1498 FUEL DOOR ACCENT for 2012 GL1800**



1. Check placement of fuel door accent on bike.
2. Clear area where the fuel door accent will go with alcohol pad provided.
3. Remove the backing on two-sided tape.
4. Carefully place fuel door accent piece in place, hold for 30 seconds. Do not ride bike for 24 hours to ensure adhesive is set.

133 Gold St, Worcester, MA 01608 508-791-7552 800-821-9861 fax 508-793-2919 email: [info@addonaccessories.net](mailto:info@addonaccessories.net)