



INSTRUCTIONS FOR 45-1612 GL1800 DRIVER BOARDS

Note: Read instructions thoroughly before installing.

1. Place bike on center stand.
2. Remove driver foot pegs by pulling cotter key and sliding out pin and washer. Save Cotter key, pin and washer to use install new boards. Remove spring. Spring will not be reinstalled.



3. Install chrome clevis using pin, washer and cotter key.
4. Install board on to clevis and secure with socket head bolt.

