



MOUNTING INSTRUCTION FOR GL1800 2012 Chrome Top Rear Fender Accent PART NUMBER 45-1899

Note: Read instruction thoroughly before installing.

1. Clean area thoroughly with alcohol pad provided.
2. Place chrome accent on the rear fender top cover that goes over the license plate light to check fitment.
3. Remove cover over two sided tape.
4. Attach chrome accent and press on firmly for 2 minutes.
5. Do not ride bike for 24 hour to insure secure hold for adhesive tape.

