



## Installation Instructions for Part M60-6611 Adjustable Rear View Mirror

1. Remove hardware from packet. Place rear view mirror on lip of bike mirror and check for desired placement. Mark position.
2. Remove backing tape from protection pad and place on underside of mirror so screws will not damage the paint.
3. Using either the set screws with the Allen wrench provided or Phillips head screws, put them in the two holes. Tighten enough to prevent movement. Do not over tighten.



### For permanent mounting.

1. Remove the rearview mirror by loosening, the Phillips head screws under the mounting clip.
2. Remove all hardware from Add On part M60-6611. Place rearview housing to bottom of OEM mirror, then mark and drill two #21 drill holes in the mirror housing. Install housing with the screws and nuts provided.
3. Reinstall both mirrors.

