




Mounting Instructions for 45-1629LED GL1800 AIR INTAKE LED LIGHT KIT

center stand.

2. Find desired place for light in the air intake area, i.e. radiator grill or on air intake trim.
3. Wire the red wire into the power and the black wire to the ground of a running light.



133 Gold St, Worcester, MA 01608 508-791-7552 800-821-9861 FX 508793-2919

Email: info@addonaccessories.net www.addonaccessories.net